
PHILIPS hue





Warnings

Always make sure the luminaire is detached from the mains socket Always make sure the DC cable is detached from the power supply Staring at the operating light source may cause eye injury

#	Disassemble/dismantle steps	Tools needed
а	Unscrew 2 screws[16] and remove Plastic sealed housing[2] from base[1]	screwdriver
b	Unplag terminal block[14] and Water proof plug[15] from Plastic sealed housing[2]	
С	Unscrew 2 screws[12] from base[1]	screwdriver
d	Unscrew 2 screws[11] from base[1]	screwdriver
е	Unplag cable from hue connect[9]	
f	Unplag driver[8] cable from hue connect[9]	
g	Remove driver[8] and hue connect[9] from base[1]	
h	Breaking Reflector[5] and remove LED strip[7] from Deco ring[4]. The electrical components are not allowed to be damaged.	

* FOR LIGHT SOURCE-LED STRIP REMOVAL PLEASE SEE DOCUMENT 442295215544_L2 Removal and Test Instruction Flex LED Strip

STATUS	92900305 Adore Hu		DESIGN ID DOC 12NC	2021-09-02
NAME Li Ba		LOCAL PART ID		A3-L
CHECKED		DATE 2021-09-02		